

Ref No	Description	Part Number	Notation	Qty Reqd
00	CAPACITOR ASSY	10496038		
00	SCREW	1968998		
01	RECTIFIER HOUSING SERV PKG	10457112		
02	ROLLER BEARING	9436064		
03	RACE-ROLLER BEARING	9436063		
04	ROTOR ASSY	1968904		
05	STATOR ASSY	1968892		
06	FRAME-DE	1852726		
07	BALL BEARING ASSY	10472935		
08	FIELD COIL & SUPPORT ASSY	1969133		
09	REGULATOR	1116405		
10	HEAT SINK PACKAGE	1971670		
11	DIODE PACKAGE-NEG	1971671		
12	DIODE PACKAGE-POS	1971672		
13	HEAT SINK ASM	1971675		
14	DIODE TRIO & CAPACITOR ASSY	10472644		
15	STUD & ANTI-TURN SPRING ASSY	1969002		
16	OUTPUT TERMINAL PACKAGE	1971674		
17	RELAY TERMINAL	1971673		
18	COVER	1969000		
19	PLATE-COVER	1969001		
20	PLATE-RETAINER	10497221		
21	COLLAR	10497218		




PLATE 6073

Ref No	Description	Part Number	Notation	Qty Reqd
22	FAN	10467133		
23	LOCK WASHER-GROUND SCREW	STD HWD		
24	NUT-DIODE TRIO LEAD TO STATOR LEAD	432229		
25	NUT ASSY	1851808		
26	NUT-SHAFT	10484823		
27	SCREW ASSY	10497222		
28	SCREW	1968945		
29	SCREW	9427129		
30	SCREW ASSY	1979961		
31	SCREW ASSY	1846956		
32	SCREW ASSY	1846957		
33	SCREW ASSY	1846955		
34	SCREW ASSY	1894458		
35	SCREW ASSY	1976061		
37	SCREW ASSY	1846955		
37	SCREW	1968998		
38	WASHER	815540		
39	WASHER	815540		
41	WASHER-SHAFT NUT	10484823		
43	THRU BOLT	1968991		
44	BUSHING	1892765		
45	CAP	1970227		
46	CLIP-TERMINAL-STATOR LEADS	1969671		




PLATE 6073

Ref No	Description	Part Number	Notation	Qty Reqd
47	GASKET	1970395		
48	GROMMET	1968900		
49	INSULATION	1968930		
50	INSULATOR	1959389		
51	INSULATOR	1968901		
52	LEAD ASSY	10472645		
53	PLATE-HEAT DISSIPATING	1892791		
54	PLUG-BEARING WELL	1876813		
55	PLUG	10476561		
58	SUPPORT-LEAD	1846938		