



PLATE 6073

Ref No	Description	Part Number	Notation	Qty Reqd
01	RECTIFIER HOUSING SERV PKG	10457112		1
02	ROLLER BEARING	10500462	Outer Race & Roller - Rectifier End	1
03	RACE-ROLLER BEARING	NA	Inner Race & Roller - Rectifier End	1
04	ROTOR ASSY	1968904		1
05	STATOR ASSY	10499385		1
06	FRAME-DE	1852726		1
07	BALL BEARING ASSY	10472935		1
08	FIELD COIL & SUPPORT ASSY	1969133		1
09	REGULATOR	1116433		1
10	HEAT SINK PACKAGE	1971670		1
11	DIODE PACKAGE-NEG	1971671		1
12	DIODE PACKAGE-POS	1971672		3
13	HEAT SINK ASM	1971675		3
14	DIODE TRIO & CAPACITOR ASSY	10472644		1
15	STUD & ANTI-TURN SPRING ASSY	1969002		1
16	OUTPUT TERMINAL PACKAGE	1971674		1
17	RELAY TERMINAL PACKAGE	1971673		1
18	COVER	1969000		1
19	PLATE-COVER	1969001		1
20	PLATE-RETAINER	10497221		1
21	COLLAR	10497218		1
22	FAN	10467133		1
23	LOCK WASHER-GROUND SCREW	STD HWD	Ground Screw	1



Ref No	Description	Part Number	Notation	Qty Reqd
24	NUT-DIODE TRIO LEAD TO STATOR LEAD	432229	Diode Trio Lead to Stator Lead Atch.	3
25	NUT ASSY	1851808	Regulator Stud	1
26	NUT-SHAFT	10484823		1
27	SCREW ASSY	10497222	Bearing Retaining Atch. - DE	4
28	SCREW	1968945	Field Coil & Support Atch.	3
29	SCREW	9427129	Ground Screw	1
30	SCREW ASSY	1979961		1
31	SCREW ASSY	1846956		1
32	SCREW ASSY	1846957		1
33	SCREW ASSY	1846955		1
34	SCREW ASSY	1894458	Regulator Atch. (Ground)	1
35	SCREW ASSY	1976061	Rectifier Bridge Atch. (Insul.)	2
37	SCREW	1968998		1
37	SCREW ASSY	1846955		1
41	WASHER-SHAFT NUT	10484823		1
43	THRU BOLT	1968991		4
44	BUSHING	1892765	Mtg. Hinge - RE	1
45	CAP	1970227	Relay Term.	1
46	CLIP-TERMINAL-STATOR LEADS	1969671		1
47	GASKET	1970395		1
48	GROMMET	1968900	Stator Leads	1
49	INSULATION	1968930	Between Diode Heat Sink & Rect. Hsg.	1
50	INSULATOR	1959389		



Ref No	Description	Part Number	Notation	Qty Reqd
51	INSULATOR	1968901	Stator Lead Grommet	1
55	PLUG	10476561	Pipe - Rectifier Hsg.	1
58	SUPPORT-LEAD	1846938	Regulator Ground Lead	1